

E511



05

000000 / 00000, 0000 M145

Indexed crank handles

00:
00 000000 00, 00 000000 00 0000 000000.

00 00:
00000 (0000 00 00000).

00:
00 (RAL 9011).

0000:
00 00000 00(00 00 H10) 0 00 00 00 00 0000.

0000 0000:
00 00 00 00


0000:
000000 00 0000 (AISI 302)

00 00:
00 00 00 00 / 0000 00

0000 00:
00 00 00 M145.

00 00 00 00:
00 0 00 00 0000 00, 00000 0000 0000 00 0 00000.
00 0 00 00 00 00 0, 0000 00 0000 0000 000000 00 000000.





© Copyright
Boteco srl Unipersonale

Art.	Art.	L	R	H	D	d	m	c	A	B	h	H1	d1H10	Q	dl	L1	(g)
E511065.0001	E511065.TP0501	88,5	65	46	27	19	30	13	17	9	10	-	5	22	20	56	92
E511080.0001	E511080.TP0501	109	80	50	34	24,5	33	13	22	12	11	54	5	28	23,5	68	187
E511110.0001	E511110.TP0501	139	110	50	34	24,5	33	13	22	12	11	54	5	28	23,5	68	205