

E513



05

000 00 / 00 000, 00 00 M145

Indexed crank handles

00:

00 000000 00, 00 0 0000 00 000 00000.

00 00:

00000 (000 00 0000).

00:

00 (RAL 9011).

000:

00 00 00 000 / 0000 00 0(00 6H).

000 000:

00 00 00 00

000:

00000 00 000 (AISI 302)

00 00:

00 00 00 00 / 000 00

000 00:


00 00 00 M145.

00 00 00:

00 0 00 00 000 00, 0000 000 000 00 0 0000.

00 0 00 00 00 00 0, 00 000 000 000 0000 00 000000.





© Copyright
Boteco srl Unipersonale

Art.	Art.	L	R	H	D	d	m	c	A	B	h	H1	d16H	Q	dl	L1	Boteco(g)
E513065.0001	E513065.TM0801	88,5	65	46	27	19	30	13	17	9	10	-	M8	18	20	56	96
E513065.0002	E513065.TM1001	88,5	65	46	27	19	30	13	17	9	10	-	M10	18	20	56	92
E513065.0003	E513065.TM1201	88,5	65	46	27	19	30	13	17	9	10	-	M12	18	20	56	91
E513080.0001	E513080.TM1201	109	80	50	34	24,5	33	13	22	12	11	54	M12	22	23,5	68	177
E513080.0002	E513080.TM1401	109	80	50	34	24,5	33	13	22	12	11	54	M14	22	23,5	68	179
E513080.0003	E513080.TM1601	109	80	50	34	24,5	33	13	22	12	11	54	M16	22	23,5	68	169
E513110.0001	E513110.TM1201	139	110	50	34	24,5	33	13	22	12	11	54	M12	22	23,5	68	196
E513110.0002	E513110.TM1401	139	110	50	34	24,5	33	13	22	12	11	54	M14	22	23,5	68	200
E513110.0003	E513110.TM1601	139	110	50	34	24,5	33	13	22	12	11	54	M16	22	23,5	68	205