

E517



05 **000 00 / 00 000, 00 00 M129** Indexed crank handles

00:
00 000000 00, 00 0 0000 00 000 00000.

00 00:
0000 (000 00 0000).

00:
00 (RAL 9011).

000:
00 00 00 000 / 0000 00 0(00 6H).

000 000:
00 00 00 00


000:
00000 00 000 (AISI 302)

00 00:
00 00 00 00 / 000 00

000 00:
000 00: 00 00 00 M129.

00 00 00:
00 0 00 00 000 00, 0000 000 000 00 0 0000.
00 0 00 00 00 00 0, 000 00 000 000 000 000 00 00000.





© Copyright
Boteco srl Unipersonale

Art.	Art.	L	R	H	D	d	m	c	A	B	h	H1	d16H	Q	dl	L1	(g)
E517065.0001	E517065.TM0801	88,5	65	46	27	19	30	13	20	9	10	-	M8	18	20	52	106
E517065.0002	E517065.TM1001	88,5	65	46	27	19	30	13	20	9	10	-	M10	18	20	52	102
E517065.0003	E517065.TM1201	88,5	65	46	27	19	30	13	20	9	10	-	M12	18	20	52	102
E517080.0001	E517080.TM1201	109	80	50	34	24,5	33	13	23,5	12	11	54	M12	22	23,5	63	187
E517080.0002	E517080.TM1401	109	80	50	34	24,5	33	13	23,5	12	11	54	M14	22	23,5	63	189
E517080.0003	E517080.TM1601	109	80	50	34	24,5	33	13	23,5	12	11	54	M16	22	23,5	63	179
E517110.0001	E517110.TM1201	139	110	50	34	24,5	33	13	23,5	12	11	54	M12	22	23,5	63	206
E517110.0002	E517110.TM1401	139	110	50	34	24,5	33	13	23,5	12	11	54	M14	22	23,5	63	198
E517110.0003	E517110.TM1601	139	110	50	34	24,5	33	13	23,5	12	11	54	M16	22	23,5	63	196