

E520



05

000 00 / 0 000, 00 00

Indexed crank handles

00:

00 00000 00, 00 0 0000 00 000 00000.

00 00:

0000 (000 00 0000).

00:

00 (RAL 9011).

000:

00 0000 00(00 00 H10) 0 00 00 00 00 000.

000 000:

00 00 00 00

000:

00000 00 000 (AISI 302)

00 00:

00 00 00 00 / 000 00

000 00:


000 000 00 M144.

00 00 00:

00 0 00 00 000 00, 0000 000 000 00 0 0000.

00 0 00 00 00 00 0, 00 000 000 000 0000 00 000000.





© Copyright
Boteco srl Unipersonale

??	Art.	L	R	H	D	d	m	c	A	B	h	H1	d1	H10	Q	dl	L1	??(g)
E520065.0003	E520065.TP0501	88,5	65	46	27	19	29	13	17	9	10	-	5	22	19	54	83	
E520080.0006	E520080.TP0501	109	80	50	34	24,5	33	13	22	12	11	54	5	28	21	66	177	
E520110.0004	E520110.TP0501	139	110	50	34	24,5	33	13	22	12	11	54	5	28	21	66	200	