


F288



06

06000000 / 000000000000, 000000

Cross handwheels

06:

00 000000

000 00000 00

00 00:

00000 (000 00 00000).

00:

00 (RAL 9011).

0000:

F288:

00000 00 00 0000 00 00 00 0000(000 00 6H).




F288PIN:

00000 00 00 0000 00 0000000 0000(AISI 303)(000 00 6H).

00 00 00:

00 00 00 0000, 00 d1 0 0000 00 00

00 0 0 00 00 00 0 0000 0000 00 000000 (00: 00 0000 00000000).



F288 22 x 22 22 22

22	Art.	D	d	d2	d3	H	h3	m	c	d1 6H	Q	22(g)
F28832.0001	F28832.TM0601	32	13	15	8	22	4	11	11	M6	18	21
F28840.0001	F28840.TM0801	40	14	16	11	24	6	12	12	M8	18	28
F28850.0001	F28850.TM1001	50	18	20	14	29	7	15	14	M10	22	49
F28860.0001	F28860.TM1201	60	20	24	16	34	6	18	16	M12	28	81

F288 PIN 22: 22222 22 AISI 303

22	Art.	D	d	d2	d3	H	h3	m	c	d1 6H	Q	22(g)
F28832.0002	F28832.TM0601PIN	32	13	15	8	22	4	11	11	M6	18	21
F28840.0002	F28840.TM0801PIN	40	14	16	11	24	6	12	12	M8	18	28
F28850.0002	F28850.TM1001PIN	50	18	20	14	29	7	15	14	M10	22	49
F28860.0002	F28860.TM1201PIN	60	20	24	16	34	6	18	16	M12	28	81